

TORQUE SPECIFICATIONS

DESCRIPTION	N·m	Ft. Lbs.	In. Lbs.	COMMENT
Brake Caliper Adapter to Knuckle Bolts - Front	50 Plus 20°	37 Plus 20°	—	* New Fastener: Do not reuse these fasteners. If removed, a new fastener must be installed and tightened to specifications.
Brake Caliper Adapter to Knuckle Bolts - Rear	105	77	—	
Brake Caliper Bleed Screws	1	—	9	
Brake Caliper to Caliper Adaptor Bolts - Front	105	77	—	
Brake Caliper to Caliper Adaptor Bolts - Rear	27	20	—	
Brake Caliper to Knuckle Bolts - Rear (Quadrifoglio)	105	77	—	
Brake Hose to Brake Caliper - Rear	16	12	—	
Brake Hose to Rigid Brake Tube - Rear	16	12	—	
Brake Rotor to Hub Bolt - Front	7	—	62	
Brake Rotor to Hub Bolt - Rear	7	—	62	
Brake Tube to Brake Caliper Nut - Front	16	12	—	
Brake Tube to ICU Nuts	16	12	—	
Dust Shield to Knuckle Bolts	9	—	80	

DESCRIPTION	N·m	Ft. Lbs.	In. Lbs.	COMMENT
Electric Park Brake (EPB) Actuator to Caliper Bolts	10	—	89	* New Fastener: Do not reuse these fasteners. If removed, a new fastener must be installed and tightened to specifications.
Electric Park Brake (EPB) Caliper to Knuckle Bolts - Rear (Quadrifoglio)	30 Plus 45°	—	—	* New Fastener: Do not reuse these fasteners. If removed, a new fastener must be installed and tightened to specifications.
ICU to Body Bolt			—	
Pedal Assembly to Bulkhead Nuts	22	16	—	* New Fastener: Do not reuse these fasteners. If removed, a new fastener must be installed and tightened to specifications.
Pedal Assembly to ICU Nuts	22	16	—	* New Fastener: Do not reuse these fasteners. If removed, a new fastener must be installed and tightened to specifications.
Wheel Speed Sensor Head to Knuckle Bolt - Front	9	—	80	

DESCRIPTION	N·m	Ft. Lbs.	In. Lbs.	COMMENT
Wheel Speed Sensor Head to Knuckle Bolt - Rear	9	—	80	